

ANNEALING FURNACE MODEL 414

User Maintenance Manual/Handbook

**Isothermal Technology Limited, Pine Grove, Southport, PR9 9AG, England
Tel: +44 (0)1704 543830 Fax: +44 (0)1704 544799 Internet: www.isotech.co.uk E-mail: info@isotech.co.uk**

The company is always willing to give technical advice and assistance where appropriate. Equally, because of the programme of continual development and improvement we reserve the right to amend or alter characteristics and design without prior notice. This publication is for information only.


CONTENTS

EMC INFORMATION.....	3
ELECTRICAL SAFETY.....	3
HEALTH AND SAFETY INSTRUCTIONS	4
GUARANTEE.....	5
CAUTIONARY NOTE.....	6
UNPACKING AND INITIAL INSPECTION	7
ELECTRICITY SUPPLY.....	7
SPECIFICATION.....	8
MODEL 414 ANNEALING FURNACE INTRODUCTION	9
ANNEALING FURNACE	10
OPERATION.....	11
<i>Altering the Furnace Temperature, (Setpoint)</i>	<i>11</i>
COMMISSIONING	12
ELIMINATING CONTAMINATION DURING THE CALIBRATION OF HIGH TEMPERATURE THERMOMETERS..	13
IMPORTANT NOTE.....	14
MAINTENANCE	15
GENERAL LAYOUT	16

CE EMC INFORMATION

This product meets the requirements of the European Directive on Electromagnetic Compatibility (EMC) 89/336/EEC as amended by EC Directive 92/31/EEC and the European Low Voltage Directive 73/25/EEC, amended by 93/68/EEC. To ensure emission compliance please ensure that any serial communications connecting leads are fully screened.

The product meets the susceptibility requirements of EN 50082-1, criterion B.

Symbol Identification	Publication	Description
	ISO3864	Caution (refer to handbook)
	IEC 417	Caution, Hot Surface

ELECTRICAL SAFETY

This equipment must be correctly earthed.

This equipment is a Class I Appliance. A protective earth is used to ensure the conductive parts can not become live in the event of a failure of the insulation.

The protective conductor of the flexible mains cable which is coloured green/yellow **MUST** be connected to a suitable earth.

The blue conductor should be connected to Neutral and the Brown conductor to Live (Line).

Warning: Internal mains voltage hazard. Do not remove the panels.

There are no user serviceable parts inside. Contact your nearest Isotech agent for repair.

Voltage transients on the supply must not exceed 2.5kV.

Conductive pollution, e.g. Carbon dust, must be excluded from the apparatus. EN61010 pollution degrees 2.

HEALTH AND SAFETY INSTRUCTIONS

1. Read this entire handbook before use.
2. Wear appropriate protective clothing.
3. Operators of this equipment should be adequately trained in the handling of hot and cold items and liquids.
4. Do not use the apparatus for jobs other than those for which it was designed, i.e. the calibration of thermometers.
5. Do not handle the apparatus when it is hot (or cold), unless wearing the appropriate protective clothing and having the necessary training.
6. Do not drill, modify or otherwise change the shape of the apparatus.
7. Do not dismantle the apparatus.
8. Do not use the apparatus outside its recommended temperature range.
9. If cased, do not return the apparatus to its carrying case until the unit has cooled.
10. There are no user serviceable parts inside. Contact your nearest Isotech agent for repair.
11. Ensure materials, especially flammable materials are kept away from hot parts of the apparatus, to prevent fire risk.

GUARANTEE

This instrument has been manufactured to exacting standards and is guaranteed for twelve months against electrical break-down or mechanical failure caused through defective material or workmanship, provided the failure is not the result of misuse. In the event of failure covered by this guarantee, the instrument must be returned, carriage paid, to the supplier for examination and will be replaced or repaired at our option.

FRAGILE CERAMIC AND/OR GLASS PARTS ARE NOT COVERED BY THIS GUARANTEE

INTERFERENCE WITH OR FAILURE TO PROPERLY MAINTAIN THIS INSTRUMENT MAY INVALIDATE THIS GUARANTEE

RECOMMENDATION

The life of your **ISOTECH** Instrument will be prolonged if regular maintenance and cleaning to remove general dust and debris is carried out.

ISOTECH

ISOTHERMAL TECHNOLOGY LTD.
PINE GROVE, SOUTHPORT
PR9 9AG, ENGLAND

TEL: +44 (0) 1704 543830/544611

FAX: +44 (0) 1704) 544799

The company is always willing to give technical advice and assistance where appropriate. Equally, because of the programme of continual development and improvement we reserve the right to amend or alter characteristics and design without prior notice. This publication is for information only.

 CAUTIONARY NOTE

ISOTECH PRODUCTS ARE INTENDED FOR USE BY TECHNICALLY TRAINED AND COMPETENT PERSONNEL FAMILIAR WITH GOOD MEASUREMENT PRACTICES.

IT IS EXPECTED THAT PERSONNEL USING THIS EQUIPMENT WILL BE COMPETENT WITH THE MANAGEMENT OF APPARATUS WHICH MAY BE POWERED OR UNDER EXTREMES OF TEMPERATURE, AND ARE ABLE TO APPRECIATE THE HAZARDS WHICH MAY BE ASSOCIATED WITH, AND THE PRECAUTIONS TO BE TAKEN WITH, SUCH EQUIPMENT.

UNPACKING AND INITIAL INSPECTION

Our packing department uses custom designed packaging to send out your unit, but as accidents can still happen in transit, you are advised, after unpacking the unit, to inspect it for any sign of shipping damage, and confirm that your delivery is in accordance with the packing note. If you find any damage or that part of the delivery is missing notify us or our agent, and the carrier immediately. If the unit is damaged you should keep the packing for possible insurance assessment.

ELECTRICITY SUPPLY

Before connecting to the electricity supply please familiarise yourself with the parts of the handbook relevant to your model.

Your unit's supply voltage requirement is specified on a plate on the instrument along with the serial number. All instruments will work on an electricity supply frequency of 50Hz or 60Hz.



The apparatus is provided with an approved power cord. If the plug is not suitable for your location then the plug should be removed and replaced with an appropriate plug.

Take care to ensure the old plug is disposed safely.

The cable is colour coded as follows:

COLOUR	FUNCTION
Green/yellow	Earth (Ground)
Brown	Live (line)
Blue	Neutral

Please ensure that your unit is correctly connected to the electricity supply.

A Residual Current Devices sometimes referred to an RCD, ELCB or ground fault detector is included with the 220/240 V unit.

SPECIFICATION

Voltage	220/240 V
Power	1000 W
Supply Frequency	50/60Hz
Maximum Operating Temperature	1000°C
Working Volume	450mm x 50mm dia approx.
Dimensions	Height 880mm Width 400mm Depth 620mm
Weight (nett)	40kg

MODEL 414 ANNEALING FURNACE INTRODUCTION

One of the duties of a calibration laboratory manager is to ensure that the S.P.R.T.'s used in the Laboratory are fully annealed and still within specification.

Just using the thermometers within the laboratory will cause work-hardening to take place within the platinum coil of the SPRT.

Therefore regular annealing is required to ensure the S.P.R.T.'s are in an ideal condition.

In 1990 the new temperature scale ITS-90 specified the use of S.P.R.T.'s up to the Silver point (961.78°C). At these temperatures quartz is very porous and in reducing atmospheres the S.P.R.T.'s can quickly become contaminated.

The Isotech Annealing Furnace offers a safe solution for those who wish to anneal S.P.R.T.'s up to 1000°C.

ANNEALING FURNACE


The Annealing Furnace has two independent control systems, one for temperature control and the other for over-temperature protection.

The furnace uses a Eurotherm 2116 over-temperature cut-off controller. On these models RESET button is located below the over-temperature controller. The SP value should be set approximately 50°C higher than the operating controller setting. If this limit should be exceeded the red push button switch will reset the apparatus once the furnace temperature has fallen below the SP value.

To turn on system power at start up (or as required), it is necessary to depress the red push button.

Altering the Alarm Temperature, (Setpoint)

1. Switch the unit on.
2. The controller will briefly show its software version before displaying an indication of the furnace temperature.



3. Momentarily press either the UP or DOWN key once to display the alarm setpoint. This value should be set to 50°C approximately above the operating controller temperature.
4. To alter the value press and hold the UP key to raise the value or the DOWN key to lower the value.
5. The display will return to show the nominal furnace temperature when no key is pressed for 0.5 second.

OPERATION


Altering the Furnace Temperature, (Setpoint)

1. Switch the unit on. The power switch is located on the power entry module, front panel.



NOTE: Do not switch the unit off until the block has cooled. Preferably below 200°C but not above 600°C or damage to the controller may occur.

2. The controller will briefly show its software version before displaying an indication of the block temperature.



3. Momentarily press either the UP or DOWN key once to display the setpoint (desired temperature).
4. To alter the value press and hold the UP key to raise the value or the DOWN key to lower the value.
5. The display will return to show the nominal block temperature when no key is pressed for 0.5 second.



The other controller functions are hidden from the operator. The values are pre-set and should not be changed.

COMMISSIONING

Connect the 3 core supply cable to a plug capable of passing up to 13 amps.

Plug in, and switch on. Press the red reset button; this will energise the apparatus.

The rate of change of temperature for the ceramic furnace liner at low temperature must be controlled, and for this reason the furnace controller has been pre-programmed to warm up slowly to its working temperature. The parameters used to effect this control are not directly accessible, for safety reasons.

Set the main controller to 100°C and the over-temperature controller to 150°C.

When the main controller has stabilised. Reduce the over-temperature controllers setting until the relay operates and the apparatus has switched off.

The apparatus is now ready for use.

All other controller functions are hidden from the operator. The values are preset and should not be changed.

The annealing/pre-heating furnace controller has been pre-set to produce a slow change in temperature, in line with the heating and cooling rates recommended for annealing of thermometers. Do not over-ride the control settings.


The recrystallised alumina liner has a closed end and thermometers may be placed directly into the liner for annealing. However, for high temperature applications, the use of a supplementary kit is recommended, as described later.

ELIMINATING CONTAMINATION DURING THE CALIBRATION OF HIGH TEMPERATURE THERMOMETERS

It is quite feasible to heat a high temperature thermometer to 1000°C and return it to ambient temperature without altering the water triple point resistance value by more than 0.5mK equivalent.

Instructions in the Isotech 962 and 96178 thermometer handbooks explain how to handle and keep clean the thermometers. It is imperative that procedures are followed because contaminants can penetrate and pass through physically-intact quartz sheaths at temperatures above 800°C.

The completed assembly is depicted below:



Air percolates through the quartz wool oxidising any pollutants and rendering them harmless and unable to penetrate the quartz sheath of the thermometer.

The combination of air-flow and positioning ensures that thermometers will not become contaminated at high temperature.

An air pump is fitted internally and runs continuously. The supplied quartz tube is connected to the air outlet via the plastic hose. Ensure that the metal pipe fitting is pushed fully into the air outlet, a sharp click is heard when the components correctly mate. The air flow rate can be adjusted from the front panel control.

IMPORTANT NOTE

Since the calibration of sensors at high temperatures can be fraught with difficulties, if any doubt exists, please consult Isotech for advice before embarking on any exercise in which there is a risk of contamination of the sensors you are trying to calibrate.

MAINTENANCE


Unless damaged in transit, the apparatus should operate for many years without maintenance or fault.

It has been common practice in the past to list a number of possible fault modes and corrective actions. However, our experience suggests that the very low incidence of failure almost implies modes not encountered previously and, therefore, not easy to envisage before-hand.

Therefore, we now prefer to work differently. With international communications so good these days, if anything goes wrong with the apparatus, or you need any other after sales service, please contact Isotech by telephone, fax or e-mail (or the agent from whom you purchased the apparatus). On our help-line we are anxious to serve you and will swiftly be able to help you solve your problem, or deal with a technical enquiry.

GENERAL LAYOUT

FRONT VIEW



REAR VIEW

